

Section C - Bases

McCOY MILLWORK

Custom Shop Services

For custom profiles pricing is determined by the chosen species of wood and quantity. Provide the following:

1. A sample or scale drawing of the profile.
2. Amount of moulding needed in Lineal Feet.
3. Preferred species of wood.
4. Preferred final finish (paint or stain).


Send us your information via email or come in for a quote. You can expect to hear from us regarding pricing in 2 days.

Manufacturing time varies: 2 days-2 weeks.

Profile #	Pg #	Profile #	Pg #	Profile #	Pg #	Profile #	Pg #
114-BV Base	99	216-BV Variable Base	105	393-B3 Step Base	118	‡920-P1 Base Cap	103
115-BV Variable Base	112	217-BV* Base	103	412-B3* Base	108	922-MV Base	114
135-B2 Base	117	219-MV Base	116	414-BV* Base	108	925-P1 Ogee Cap	103
154-B2 Ogee Step Base	101	230-B2* Base	120	‡ 415-BV Base	109	926-P1 Ogee Cap	103
160-BV Base	114	231-B2 Base	120	433-M1 Base Shoe	120	929-PV Ogee Cap	103
161-BV* Base	114	232-B2 Base	120	‡ 452 M1 Base Shoe	120	934B-P1 Base Shoe	120
162-BV Variable Base	114	232B-B2 Base	120	453-M1 Base Shoe	120	937-BV Ogee	103
163-BV* Base	114	233-B2 Sanitary Base	120	516B-BV Reversa Ogee Base	104	943-B4 Cove Top Base	111
164B-B2 Base	104	234-B2 Base	120	516C-BV Variable Base	104	944-BV Base	111
164-BV Base	114	235-BV San Base	120	531-B3 Base	110	960-MV Base	111
167-BV* Base	112	236-B2 Base	120	590-BV Base	116	961-MV Base	116
168-BV Base	109	‡ 237 BV Base	116	604-B2 Base	116	993B-BV Variable Base	108
169-BV Base	114	250-B2* Base	119	620-B3 Base	111	993-BV Base	108
176-BV Base	112	251-B2 Base	119	731-MV Base	104	994-BV Base	109
182-MV Base	111	259-B2 Base	106	732-MV Ogee	103	995-B2 Base	108
186-B2* Base	116	259B-B2 Base	106	735-MV Base	104	996-BV Base	108
186B-B3 Base	116	267-B4* Base	107	736B-BV Base	104	997-BV Variable Base	109
‡ 188 BV Base	115	270-B2 Base	119	736-BV Base	104	998-B2 Base	107
200-M1* Base Shoe	120	271-B3 Base	119	736C-BV Var Base	104	1037-T2 Plinth/Casing	97
201B-B4 Base	113	273-B2 Base	119	736E-BV Var Base	115	1116-BV Variable Base	109
202-BV Variable Base	99	277-BV Sanitary Base	119	771-MV Misc/Plinth	95	1155-BV Ogee Base	101
203-B4 Base	98	278-B2 San Base	119	802-BV Base	112	1202-BV Base	118
204-B2* Base	119	279-BV* Sanitary Base	119	806-BV Variable Base	110	1205-BV Variable Base	107
‡ 204B-B2 San Base	119	280-B2* Ogee Base	102	809-BV Base	110	1209-BV Var Base	105
204-BV* Base	119	281-B2 Ogee Base	102	810-BV Base	109	1210-BV Variable Base	105
205-B2 Base	119	‡ 282 BV Base	114	811-BV Base	108	1217-BV Variable Base	105
206-BV Variable Base	117	284-BV* Ogee Base	102	813-BV Ogee Base	103	1255-B4 Ogee Base	101
208-B2* Base	106	285-B4* Ogee Base	102	814-BV Base	117	1256-B4 Ogee Base	101
210-B3 Base	105	286-BV Base	103	815-BV Base	109	1259-BV Variable Base	106
211-B3* Base	105	‡ 287-BV Ogee Base	103	816-BV Variable Base	108	1260-B3 Base	106
212-B2 Base	106	288-BV Ogee Base	102	817-BV Variable Base	107	1267-BV Variable Base	109
212B-B2 Base	106	330-BV Base	115	819-BV Base	109	1268-BV Variable Base	106
213-B3 Base	105	331-BV Radius Top Base	115	822-BV Base	112	1280B-BV Ogee Base	102
214-B2 Base	106	385-MV Base	118	823-BV Base	115	1280-BV Ogee Base	102
215-B2 Cntr Bd Base	106	389-BV Base	118	917-P1 Ogee Cap	103	1281-BV Base	115
216B-B3 Base	105	391-BV Base	118	918-P1* Base Cap	103	1286B-B2 Ogee Base	103



Profile #	Pg #	Profile #	Pg #	Profile #	Pg #	Profile #	Pg #
1286-BV Ogee Base	102	2812-BV Top Bead Base	107				
1287-BV Ogee	103	2814-BV Top Bead Base	110				
1287X-BV Ogee	103	2922-B4 Variable Base	114				
1330-B2 Base	115	2925-P1 Ogee Cap	103				
1331-BV Base	104	2993-B4 Var Base	108				
1332-BV Variable Base	115	3010-B3 Base	117				
1333-BV Variable Base	114	3011-B3 Base	117				
1380-BV Variable Base	118	3705-B4 Variable Base	109				
1382-BV Variable Base	118						
1385-B4 Step Base	118	B					
1400-M2 Plinth	97	BD2-SLV Base	100				
‡ 1410-M1 Misc/Shoe	120	O					
1412-M1 Base	116	OG-SLV Base	99				
1415-BV Base	113	P					
1416-BV Variable Base	113	PL-1V Plinth	94				
1503-BV Base	116	PL-2V Plinth	94				
1697-MV Misc	103	PL-3V Plinth	94				
1815-BV Variable Base	110	PL-4V Plinth	94				
1816-B2 Base	110	PL-5V Plinth	95				
1921-BV Base	100	PL-6V Plinth	95				
2067-B4 Base	112	PL-7V Plinth	95				
2134-B4 Base	113	PL-8V Plinth	95				
2155-T2 Base	101	PL-10V Plinth	96				
2176-B4 Base	112	PL-11V Plinth	96				
2188-B3 Base	115	PL-V9 Plinth	96				
2201-BV Base for cap	100	S					
2202-BV Base	98	SNW-451 Base Shoe	120				
2203-B4 Base	98	SNW-736 Base	115				
2204-BV Base	98						
2205-B2 Base	107						
2245-B4 Base	112						
2267-B4 Base	107						
2270-BV Top bead base	108						
2280-BV Ogee Base	102						
2283-B4 Ogee base	102						
2284-PV Base/Cap	103						
2286-B4 Ogee base	102						
2385-BV Step Base	118						
2389-B4 Base	118						
2390-B3 Base	112						
2400-M1 Base Shoe	120						
2415-B4 Base	113						
2426-B4 Base	114						
2486-T4 Base	116						
2713-B2 Base	110						
2715-B4 Base for cap	99						
2809-B2 Base	110						




PL 1V
1 5/16 x Var




PL 2V
1 1/16 x Var




PL 3V
1 1/16 x Var




PL 4V
7/8 x Var








Plinth for casing 248 P2
pair with Base 331 BV







Designed for use
with Base Cap
708 P1







Designed for use
with Base Cap
2811-P2







1256-B4
 $\frac{3}{4} \times 7 \frac{5}{8}$




1255-B4
 $\frac{3}{4} \times 6$




1155-BV
 $\frac{1}{16} \times \text{Var}$



2155-T2
 $\frac{5}{8} \times 3 \frac{3}{4}$



154-B2
 $\frac{7}{8} \times 3 \frac{5}{8}$





‡ Sample missing



1286B-B2
5/16 X 3 5/8




‡ 287-BV
1/2 x Var




217-BV*
3/8 x Var



286-BV
7/16 x Var




813-BV
7/8 x Var




1697-MV
1 3/16 x Var




732-MV
Var x 3/4




1287-BV
3/4 x Var




937-BV
3/4 X Var




1287X-BV
1 1/16 x Var




929-PV
1 7/32 X 1 1/16



926-P1
3/4 X 1 5/16




925-P1
3/4 X 1 5/16




2925-P1
5/8 X 3/4




2284-PV
1 7/32 X Var




917-P1
9/16 X 1 1/16



‡920-P1
7/16 X 3/4



918-P1*
3/8 X 1/2



736B-BV
 $\frac{9}{16} \times 5 \frac{1}{2}$




736C-BV
 $\frac{3}{4} \times \text{Var}$




736-BV
 $\frac{1}{2} \times \text{Var}$



735-MV
 $\frac{3}{4} \times 3$




731-MV
 $\frac{3}{4} \times \text{Var}$



516B-BV
 $\frac{5}{8} \times \text{Var}$



1331-BV
 $1 \frac{13}{32} \times 3 \frac{1}{4}$



164B-B2
 $1 \times 3 \frac{7}{16}$



516C-BV
 $1 \frac{3}{16} \times \text{VAR}$



1210-BV
 $\frac{9}{16}$ x Var




1209-BV
 $\frac{9}{16}$ X Var



210-B3
 $\frac{5}{8}$ x $4 \frac{7}{16}$



1217-BV
 $1 \frac{1}{32}$ x Var



216B-B3
1 x $4 \frac{3}{16}$



211-B3*
 $\frac{3}{4}$ X $4 \frac{3}{16}$



213-B3
 $\frac{25}{32}$ X $4 \frac{1}{16}$



216-BV
 $\frac{3}{4}$ x Var



CENTER BEAD BASES



215-B2
 $\frac{9}{16} \times 3 \frac{1}{8}$



214-B2
 $1 \frac{7}{32} \times 3 \frac{3}{16}$




212 B2
 $\frac{9}{16} \times 3 \frac{1}{8}$




212B-B2
 $\frac{9}{16} \times 3 \frac{1}{16}$



COLONIAL BASES



1260-B3
 $\frac{3}{4} \times 4 \frac{3}{4}$



1259 BV
 $\frac{1}{2} \times \text{Var}$




1268-BV
 $\frac{9}{16} \times \text{Var}$




259B-B2
 $\frac{9}{16} \times 3 \frac{1}{4}$



259-B2
 $\frac{1}{2} \times 3 \frac{1}{16}$



208-B2*
 $\frac{1}{2} \times 3 \frac{1}{8}$



2267-B4
25/32 X 9 1/4



2812-BV
3/4 x Var



267 B4*
1/2 X 5 3/16



1205 BV
17/32 x Var



817 BV
9/16 x Var



998 B2
9/16 X 3 1/2



2205-B2
1/2 X 3 7/8



‡ Sample missing



2993-B4
5/8 x Var



996 BV
5/8 x 5 1/2



993 BV
5/8 x Var



811 BV
3/4 x Var



993B-BV
1 1/16 x Var



995 B2
1 1/16 x 3 7/16




2270-BV
3/4 x Var



816 BV
5/8 x 5




412 B3*
5/8 x Var



414 BV*
5/8 x Var



‡ Sample missing



815-BV
3/8 x Var




‡ 415-BV
1/2 x Var



168-BV
5/8 x Var



994-BV
9/16 x 3 3/8



1116 BV
3/4 x Var



3705-B4
9/16 X Var



997-BV
3/4 x Var



1267 BV
9/16 x Var




819 BV
3/4 x Var



810 BV
3/4 x Var




2814-BV
5/8 x Var



531-B3
9/16 x 4



809-BV
3/4 x Var



2713-B2
15/16 x 3



1815-BV
9/16 x 3 1/8





1816-B2
3/4 x 3




806-BV
9/16 x Var



2809-B2
5/8 x 2 7/8





802-BV
3/4 x Var

167 BV
9/16 x Var

822-BV
3/4 x Var

2067-B4
5/8 x 6 1/2




115 BV
5/8 x Var

2176-B4
3/4 x 4 1/16

2245-B4
5/8 x 4 1/2

2390-B3
7/8 x 4 1/2

176 BV
9/16 x 4 7/16





‡ Sample missing



160 BV
 $\frac{13}{32} \times \text{Var}$



162 BV
 $\frac{9}{16} \times \text{Var}$




169 BV
 $\frac{5}{8} \times \text{Var}$



161 BV*
 $\frac{5}{8} \times \text{Var}$



163 BV*
 $\frac{5}{8} \times \text{Var}$




164 BV
 $\frac{13}{16} \times \text{Var}$




‡ 282 BV
 $\frac{3}{4} \times \text{Var}$




1333-BV
 $\frac{1}{2} \times \text{Var}$



922 MV
 $\frac{3}{4} \times \text{Var}$



2922-B4
 $\frac{3}{4} \times \text{Var}$



2426-B4
 $\frac{7}{8} \times \text{Variable}$



‡ Sample missing



2188-B3
 $\frac{9}{16}$ X 4 $\frac{9}{16}$




736E-BV
 $\frac{1}{2}$ x Var




SNW-736
 $\frac{3}{4}$ x Var (7 $\frac{1}{2}$)



‡ 188 BV
 $\frac{5}{8}$ x Var



823-BV
 $\frac{1}{16}$ x Var




330 BV
 $\frac{5}{8}$ x Var



1281 BV
 $\frac{5}{8}$ x Var



1330 B2
 $\frac{3}{4}$ X 3 $\frac{3}{8}$



1332 BV
 $\frac{13}{16}$ x Var




Pair with Casing 248 P2
 and Plinth 1037 T2


331-BV
 $\frac{1}{16}$ x Var



‡ Sample missing



1412 M1
1/4 - 1/2 groove




219 MV
1/16 x Var




‡ 237 BV
3/4 x Var



961 MV
3/4 x Var




186B-B3
13/16 4 1/2



590 BV
5/8 x 5 1/4




186 B2*
1/16 x 3 1/2







2486-T4
1/16 x 7




1503 BV
5/16 x Var




604 B2
3/4 x 3 7/16





391 BV
3/4 x Var




1202 BV
5/8 x Var




1380 BV
2 1/32 x Var



1382 BV
23/32 x Var



389 BV
5/8 x Var



1385-B4
3/4 x 6




2385-BV
3/4 x Var



2389-B4
13/16 x 5 3/8




393 B3
9/16 x 4 1/4



385 MV
1/2 x 4 3/16




‡ Sample missing



271-B3
5/8 x 4 1/2




279-BV*
7/16 x Var




204-B2*
5/8 x 3 1/2




‡ 204B-B2
5/8 x 3 1/2



278-B2
1/2 x Var




251-B2
7/16 x 2 1/4



205-B2
3/4 x 3 1/2



277-BV
1/2 x 3 1/2




273-B2
9/16 x 3 5/16



270-B2*
7/16 x 3 1/4




204-BV
7/16 x Var



250-B2*
7/16 x 2 1/4




234-B2
5/8 X 3 1/2



232B-B2
13/16 X 3 9/16



236-B2
3/4 X 3 1/2



231-B2
1 1/16 X 2 1/2




232-B2
9/16 X 2 1/2



235-BV
13/16 X 2



233-B2
3/4 X 2




230-B2*
9/16 X 2 3/16




BASE SHOES




‡ Sample missing



‡ 1410-M1
1/2 X 1 1/4




‡ 452-M1
3/4 X 1



433-M1
3/8 X 7/8




2400-M1
7/16 X 13/16




200-M1*
1/2 X 3/4



453-M1
7/16 X 3/4



SNW-451
1/2 X 3/4



934B-P1
9/16 X 1/2